



6320 E Stassney Ln. Phone / 1.800.615.8350  
Austin, TX 78744 Email / sales@feniex.com



---

## Q Series

### How to Program Q Serial Cruise Mode

Programming cruise mode with any of the 5 available colors on your light heads is really straightforward. Using the Q Link software program, let me show you how that's done. On a typical cruise mode, you'd have 1 color on one half of the vehicle, another color on the other half of the vehicle. Since I have 6 modules, I'll program 3 modules on Zone 8 and 3 modules on Zone 9. I'll start by activating Input 28, which is my zone programming wire. I'll connect that to power. Click my zone tab, select Zone 8. Blue will illuminate. I'll activate 3 modules to Zone 8. I'll click Zone 9. Activate 3 modules to Zone 9. Uh, now select input and put 1 cruise signal brightness at 10%. And on Zone 8, I'll program that to red. And on Zone 9, I'll program that to blue. I'll go ahead and program Input 2 as cruise signal at 100% red on Zone 8, blue on Zone 2. On Input 3, I can program a different color. Let's just go ahead and go with green on Zone 8 and amber on Zone 2, I program my device. I'll now disconnect my zone programming wire. Activate live mode and turn on Input 1, which is Zone 8 in red and Zone 9 in blue at 10%. Input 2 is 100% Zone 8 and Zone 9. And of course, Input 3 is green and amber, Zone 8 and Zone 9. This concludes how you set up cruise mode using this system.