

GUARDIAN®

FLASHLIGHT



GUARDIAN FLASHLIGHT

FL-001

Equipment Dimensions ▲
pp. 03

Specifications ▲
pp.03

Basic Functions & Charging ▲
pp.04



SAFETY REGULATIONS & WARRANTY

Safety Regulations

The following provides all the information necessary to safely operate the previously listed products of Feniex Industries, Inc. Please read this manual thoroughly before installing or operating your new product in order to prevent any damage or injury. Failure to follow the listed instructions in this manual may result in damage to your products or personal injury.

- Proper installation of this product requires good knowledge of automotive systems, electronics and procedures.
- Please guarantee all vital components of the vehicle are not in danger of being damaged by drilling holes necessary for installation. Check all sides of the mounting surface before drilling any holes into the vehicle.
- Do not install this product in any way that interferes with the deployment of the air bag. Doing so may damage the effectiveness of the air bag and can lead to serious personal and vehicle injury. The installer will assume full responsibility of proper installation of the new unit.
- Please clean the mounting surface before installation of the unit when using tape, brackets, magnet, Velcro or suction cups.
- The product's ground wire must be connected directly to the Negative (-) battery post for effective use of the unit. Please follow all wiring guidelines provided to guarantee long lifespan and productivity. Failing to follow these instructions may result in damage to the product.

Warranty

Feniex Industries' speakers, sirens, rocker panels, AM600 Beacons, Torch Lights, AI lightbars, AI Cubes, AM900 Work Lights and controllers are warranted for 2 years from the manufacturing date. In addition, all other products are warranted for 5 years from the manufacturing date.

If a warranty problem occurs, please contact customer support at 1.800.615.8350 or visit the web site at www.Feniex.com. If the product needs to be returned for repair or replacement, call our customer support line to receive a return merchandise authorization number.

Operational times are from 10 a.m. to 5 p.m. central time, Monday through Friday. Please do not send in product without contacting support first for a RMA number.

Service After Expiration

Feniex Industries will still provide service for all products after expiration of the warranty. For any issues, call the customer support line. In some instances it may be necessary for the product to be shipped, freight prepaid and insured for loss or damage to Feniex headquarters.

Warning! Utilizing non-factory screws and mounting brackets may result in loss of warranty coverage.

Copyright

This instruction manual and the Feniex products described in this instruction manual may include or describe copyrighted Feniex material. Laws in the United States and other countries preserve for Feniex Industries and its licensors certain exclusive rights for copyrighted material, including the exclusive right to copy, reproduce in any form, distribute and make derivative works of the copyrighted material. Accordingly, any copyrighted material of Feniex and its licensors contained herein or in the Feniex products described in this instruction manual may not be copied, reproduced, distributed, merged or modified in any manner without the express written permission of Feniex Industries, Inc.

Feniex Product Copyrights

The products described in this document are the property of Feniex Industries, Inc. It is furnished by express license agreement only and may be used only in accordance with the terms of such an agreement. Products and documentation are copyrighted materials. Making unauthorized copies is prohibited by law. No part of the product or documentation may be reproduced, transmitted, transcribed, stored in retrieval system or translated into any language or computer language, in any form or by any means, without prior permission from Feniex Industries, Inc.



▲ SPECIFICATIONS

Dimensions	7.9" x 1.75" x 1.75"
Warranty	2 years
Certification	CE, RoHS
Battery	Lithium Rechargeable Battery
Voltage	12 Volts DC
Power	<5W
IP Rate	IP44
Weight	0.85oz

▲ EQUIPMENT DIMENSIONS



▲ GETTING STARTED

Follow the steps below to install the battery.

1. Unscrew the removable endcap from the base of the flashlight.
2. Use the provided lithium rechargeable battery to install into the base of the flashlight.

IMPORTANT: Install the battery with the positive side first (see fig. 3).

3. Secure the removable endcap to the base of the flashlight.



▲ FLASHLIGHT CONTROLS



▲ CHARGING THE FLASHLIGHT

The Guardian Flashlight uses a rechargeable battery. To recharge, follow the steps below:

1. Locate the USB charge port, located on the opposite side of the power button.
2. Use the provided USB cable's USB 2.0 A-Male to plug into the flashlight's USB charge port.
3. Plug the USB Cable's Micro B into a charger.
4. The 'battery life indicator' will turn on when flashlight is charging.